



LAZER TAG

GAME GUIDE

AGES
9+

CONTENTS • 1 Blaster • 1 iPhone/iPod touch Cradle
• 1 Lazer Tag iPhone Skin • 1 Lazer Tag iPod touch Skin


NOTE: This device is not intended to provide protection to the iPhone/iPod touch. Hasbro is not responsible for damage to the iPhone/iPod touch. Blaster does not charge device.

Adult assembly required.

⚠ CAUTION:


Know your surroundings and clear the area of any obstructions before each use. To avoid fatigue and strain, take frequent breaks during use if necessary. Use caution in low-light conditions because device screen may make it more difficult to see.

1. REMOVE V-SIGHT AND TAKE OUT CABLE





2. ATTACH THE CRADLE TO BLASTER

Push cradle down until it clicks into place. Once attached it cannot be removed.




3. RELEASE LATCH AND OPEN CRADLE




4. INSERT DEVICE INTO MATCHING SKIN

- If your device has an existing skin or case, remove it.
- iPhone 3GS does not require a skin.




5. CONNECT AND INSERT YOUR DEVICE



Note: Secure loose cable to cradle by using the Cord Clips.

TO REPLACE BATTERIES

Phillips head screwdriver required.



POWER UP WITH
DURACELL
BATTERIES
NOT INCLUDED

6 1.5V AA
ALKALINE BATTERIES
REQUIRED NOT INCLUDED

IMPORTANT: BATTERY INFORMATION

⚠ CAUTION:

1. TO AVOID BATTERY LEAKAGE
 - a. Always follow the instructions carefully. Use only batteries specified and be sure to insert them correctly by matching the + and - polarity markings.
 - b. Do not mix old batteries and new batteries or standard (carbon-zinc) with alkaline batteries.
 - c. Remove exhausted or dead batteries from the product.
 - d. Remove batteries if product is not to be played with for a long time.
 - e. Do not short-circuit the supply terminals.
 - f. RECHARGEABLE BATTERIES: Do not mix these with any other types of batteries. Always remove from the product before recharging. Recharge batteries under adult supervision. DO NOT RECHARGE OTHER TYPES OF BATTERIES.
2. Should this product cause, or be affected by, local electrical interference, move it away from other electrical equipment. Reset (switching off and back on again or removing and re-inserting batteries) if necessary.

NOTE: If your blaster appears to be malfunctioning, the batteries may be running low. Insert fresh batteries to

FCC Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy, and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.
Consult the dealer or an experienced radio/TV technician for help.

Caution: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This Class B digital apparatus complies with Canadian ICES-003.

Cet appareil numérique de la classe B est conforme à la norme NMB-003 du Canada.

iPhone, iPod touch, and iTunes are trademarks of Apple Inc., registered in the U.S. and other countries. App Store is a service mark of Apple Inc.

Duracell and its logo are trademarks of Procter & Gamble and are used with permission. © 2012 Procter & Gamble. All rights reserved.

LAZER TAG is a registered trademark of Shoot the Moon Products and is used with permission.

© 2012 Hasbro, Pawtucket, RI 02862 USA. All Rights Reserved. TM & ® denote U.S. Trademarks. US Pat. No. 7632187 & Pat. Pending.

Consumer contact:

USA and Canada: Hasbro Games, Consumer Affairs Dept., P.O. Box 200, Pawtucket, RI 02861-1059 USA. ☎ 888-836-7025. Hasbro Australia Ltd., Level 2, 37-41 Oxford Street, Epping, NSW 2121, Australia.
☎ 1300 138 697. Hasbro NZ (a branch of Hasbro Australia Ltd.), 221 Albany Highway, Auckland, New Zealand. ☎ 0508 828 200.





Get to know your blaster

Cradle for
iPhone® / iPod touch®

Receiver/Hit Indicator



Indoor/Outdoor

On/Off

Reload

Shield

Trigger

Are you ready to battle your friends and take out some ugly aliens?
Then what are you waiting for? Grab your blaster and get in there!

BASIC MISSION

2 OR MORE PLAYERS

No iPhone or iPod touch needed, just power up your blaster and start shooting. You want to be the last man standing. Take 10 hits and you're out.

1. Turn your blasters on and set them to either Indoor or Outdoor based on where you'll battle.
2. Let the blasting begin! Run, hide or do whatever it takes not to get hit.

App-Enhanced Missions

Download the app then play your most adrenaline-filled LAZERTAG missions yet with the interactive app. Just connect your iPhone or iPod touch to your blaster, follow the on-screen commands and you're ready to go!



Solo Campaign

1 player

Hone your skills as you battle waves of alien enemies.



Need to download the app?

Use a smartphone to scan the code and download the app. You can also visit lazertag.com for the latest on future apps, updates and more!



Multiplayer Battle

2 to 24 players

Get a bunch of friends together and have an all-out blaster brawl in a selection of awesome multiplayer games!



Available on the
App Store